

*Four Channel  
Controller*



P/N: 77036021-1  
Revision: 1.1  
Reference Firmware: 1.25 (rev. 4.1)



**THE INFORMATION CONTAINED IN THIS MANUAL IS ACCURATE TO OUR KNOWLEDGE.**

As a result of continuous research and development, the specifications of this product may be modified at any time without prior notice.

**IMPORTANT INFORMATION**

The modification of the material and the use of parts of an unspecified origin shall entail the cancellation of any form of warranty.

The use of the unit has been projected for applications specified in the technical characteristics. Exceeding the values cannot in any case be authorized.

**LIABILITY**

Neither Oldham nor any other associated company can be held liable for any damages, including, without limitations, damages for the loss or interruption of manufacture, loss of information, defect of the WX4 unit, injuries, loss of time, financial, or material loss, or any direct or indirect consequence of loss occurring in the context of the use or impossibility of use of the product, even in the event that Oldham has been informed of such damage.

**SAFETY INSTRUCTIONS**

Labels intended to remind you of the principal precautions of use have been placed on the unit in the form of pictograms. These labels are considered an integral part of the unit. If a label falls off or becomes illegible, see to it that it is replaced.



**Warning: Read & understand contents of this manual prior to operation. Failure to do so could result in serious injury or death.**



# Table of Contents

<b>SECTION - 1</b>	<b>7</b>
Important Safety Issues	7
1.0 General Description	9
1.1 Data Display Screens	10
1.1.1 Engineering Unit Screen	10
1.1.2 Bar Graph Screen	11
1.1.3 Trend Screen	11
1.2 Specifications	11
1.2.1 Power Supply Requirements	11
1.2.2 Relays	12
1.2.3 Ambient Temperature Range	12
1.2.4 Humidity Range	12
1.2.5 Altitude	12
1.2.6 Housings / Installation Categories	12
1.2.7 Approvals	12
<b>SECTION - 2</b>	<b>13</b>
2.0 Basic Operation	13
2.1 Setup Menu Configuration	13
2.2 Changing Menu Variables Using the Keypad	14
2.2.1 WX4 Setup Configuration Menus	15
2.2.2 Channel Setup Entry Menu	15
2.2.3 FAULT / ALARM 1 / ALARM 2 / ALARM 3 SET-UP Menus	16
2.2.4 Configure Menu to Define Channel	17
2.2.5 Cal Setup Menu	18
2.2.6 Calibrate Input Menu	18
2.3 System Configuration Menus	19
2.3.1 Standard / Optional Relay Setup Menus	20
2.3.2 Relay 2 ACK (Acknowledge) / Horn Setup Menu	21
2.3.3 Clock / Delays Menu	21
2.3.4 Communications Menu	22
2.3.5 Analog Setup Menu	22
2.4 System Security Menu	23
<b>SECTION - 3</b>	<b>25</b>
3.0 Motherboard Interface PCB #10-0215	25
3.1 Input / Output Optional PCBs	27
3.1.1 Optional Analog Input PCB #10-0221-4	27
3.1.2 Optional Bridge Sensor Input Board #10-0309	28
3.1.3 Bridge Sensor Initial Setup	29
3.1.4 Optional Discrete Relay PCBs #s 10-0222	30
3.1.5 Optional 4-20mA Analog Output Board #10-0308	31
3.2 ModBus RS-232 / RS-485 Interface Option #10-0253	32

3.2.1	ModBus Register And Function Code Summary	34
3.3	Optional 24 VDC 50 Watt Power Supplies	40
<b>SECTION - 4</b>		<b>41</b>
4.0	NEMA 4x Polycarbonate Wall Mount (Extended)	41
4.1	NEMA 4 Painted Steel Wall Mount (Extended)	42
4.2	NEMA 4x Stainless Steel Wall Mount (Extended)	43
4.3	NEMA 7 Explosion-Proof Wall Mount (Extended)	44
<b>SECTION - 5</b>		<b>45</b>
5.0	Adding the "Wireless" Radio Kit Option	45
5.1	Radio Setup Menu	46
5.2	Wireless Receiver Mode	46
5.2.1	Radio Status Alarms – Wireless Receiver Mode	47
5.3	Wireless ModBus Slave Mode	48
5.4	Antenna Selection	48
5.4.1	Dipole and Collinear Antennas	48
5.4.2	Yagi Antennas	49
5.4.3	Mounting Near Other Antennas	49
5.4.4	Coax Cables	49
5.5	Surge Protection and Grounding	50
5.5.1	Antenna Grounding	50
5.5.2	Connections to Other Equipment	51

# SECTION - 1

## Important Safety Issues

The following terms and symbols are used in this manual to alert the operator of important instrument operating issues:



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions.



This symbol is intended to alert the user to the presence of dangerous voltage within the instrument enclosure that may be sufficient magnitude to constitute a risk of electric shock.



This symbol signifies the system's ground terminal

DC refers to direct current voltages.

VAC refers to alternating current voltages.



### WARNINGS:

- **Shock Hazard** - Disconnect or turn off power before servicing this instrument.
- NEMA 4X wall mount models should be fitted with a locking mechanism after installation to prevent access to high voltages by unauthorized personnel (see Figure 4.0).
- Only the combustible monitor portions of this instrument have been assessed by CSA for 122.2 No. 152 performance requirements.
- This equipment is suitable for use in Class I, Division 2, Groups A,B,C and D or non-hazardous locations only.
- **WARNING - EXPLOSION HAZARD** - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.
- **WARNING - EXPLOSION HAZARD** - DO NOT REPLACE FUSE UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.

- **WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.**
- Use a properly rated CERTIFIED AC power (mains) cable installed as per local or national codes.
- For DC powered units, DC power must be from a SELV rated source.
- A certified AC power (mains) disconnect or circuit breaker should be mounted near the controller and installed following applicable local and national codes. If a switch is used instead of a circuit breaker, a properly rated CERTIFIED fuse or current limiter is required to be installed as per local or national codes. Markings for positions of the switch or breaker should state (I) for on and (O) for off.
- Clean using only a damp cloth with no solvents.
- Equipment not used as prescribed within this manual may impair overall safety.



# 1.0 General Description

The OldhamWX4 Four Channel Controller is designed to display and control alarm event switching for up to four inputs. Inputs are typically voltage or 4-20mA current from transmitters, monitors or other analog output devices. The WX4 is equipped with a Fault and three alarm levels per channel with features such as ON / OFF delays, latching relays and alarm Acknowledge. A dedicated horn driver circuit for a local audible annunciator is also standard. Two standard 5-amp alarm relays are configurable via the “alarm voting” menu to make relays trip based upon various alarm combinations. Real-Time Clock and Calendar are also standard. Options such as 4-20mA outputs, discrete relays for each alarm and audible annunciators are easily added. RS-485 (ModBus RTU) or Ethernet (ModBus TCP) ports are also available for sending data to PC’s, PLC’s, DCS’s, or other Oldham WX-Series controllers.

A 128 x 64 pixel graphic LCD readout displays monitored data as bar graphs, 30-minute trends and engineering units. System configuration is via user friendly menus and all configuration data is retained in non-volatile memory during power interruptions. The WX4 front panel is shown below in Figure 1.0 displaying the bar graph data screen. The five button symbols below the display are magnetically activated using the supplied magnetic wand without opening the enclosure. Opening the enclosure door provides access to the “touch” keypad as shown in Figure 1.1.




Figure 1.0




Figure 1.1

## 1.1 Data Display Screens

The WX4 Controller offers three modes for displaying monitored data. Each is shown below in Figure 1.2.




Figure 1.2

### 1.1.1 Engineering Unit Screen

The WX4 Engineering Unit screen shown at left in Figure 1.2 allows each channel's value and its 10-digit Eunits tag to be viewed simultaneously. A1, A2, A3, FL icons at lower right of each reading flash if ALARM 1, 2, 3 or FAULT alarms activate for this channel.

## 1.1.2 Bar Graph Screen

Values are displayed graphically as bar graphs with alarm levels indicated by vertical dashed lines across each bar. The bar graph screen is very useful for emphasizing current reading relative to the channel's alarm setpoint. Live readings and their Eunits tag appear above each bar graph.

## 1.1.3 Trend Screen

The WX4 also provides 30-minute trend screens for each channel as shown in Figure 1.2. Live readings and their Eunits tag are displayed across the top of each trend screen. Channel numbers are shown in the upper right and are selected by the NEXT key. A1, A2 and A3 alarm levels appear as horizontal dashed lines across the screen.

# 1.2 Specifications

## 1.2.1 Power Supply Requirements

WX4 primary power may be either 10-30 VDC or 100-240 VAC. All models are equipped with an AC input / 24 VDC 15 watt output switching power supply PS1 mounted to the motherboard (see Figure 3.1). AC power requirements are 100-240 VAC 50/60 Hz @ .80 amp max (including inrush) and 40 watts max steady state, applied to TB5 on the motherboard. If AC power is not available the primary power may be 10-30 VDC applied to TB1 on the motherboard. A backup DC power source may also be connected to TB1 for automatic switchover if the AC power source fails. See Figures 3.0 & 3.1 for wiring information.

The basic WX4 consumes only 1.5 watts of 10-30 VDC power. Optional features such as relays and analog outputs increase power consumption as described below:

- 10-0221-4, **Analog Input PCB** option; add wattage for each monitor connected to this board's 24 VDC terminals.
- 10-0222, **Discrete Relay PCB** option; add 1.5 watt.
- 10-0308, **4-20mA Output PCB** option; add 1 watt.
- 10-0309, **Bridge Sensor Input PCB** option; add wattage of each sensor attached.

With an AC primary power source connected to TB1 on the motherboard, TB3 terminals 1 & 2 on the motherboard provide a maximum of 12 watts output power for powering of auxiliary external devices such as relays, lights and monitors (see Figure 3.0). Power consumed from TB3 must be included when calculating system power consumption.

**IMPORTANT!** TB3 only provides 24 VDC power when AC is primary power.

24 VDC terminals on the 10-0221-4 Analog input option (see Figure 3.3) are typically used to power external transmitters up to 10 watts per channel and these loads must also be calculated into the overall power budget. These terminals receive power from both the integral AC / DC power supply and the external TB1 supply as shown in Figure 3.0.

Some applications may require 24 VDC power in excess of that available from the WX4 AC power supply on the motherboard and thereby require another 50 watt AC/DC supply. NEC Class 2 FIFTY WATT external supplies are available for Division 1 (part #10-0314) and Division 2 (part #10-0315) potentially hazardous area installations and both also include a NEMA 4X weather rating. Contact an Oldham sales representative or visit <http://www.oldhamgas.com> for more details.

### 1.2.2 Relays

Two mechanical (dry contact) Common Form C relays are standard and may be mapped to various alarm events as described in section 2.3.1. WX4's may also be equipped with optional solid-state common Form A relays (see order guide for details) in applications requiring non-arcing switching. Solid-state relays are recommended for switching of highly inductive loads.

A six mechanical (dry contact) Discrete Relay option board (see section 3.1.6) provides dedicated Form C relays for ALARM 1, ALARM 2 and FAULT for both channels.



All mechanical (dry contact) relays are rated at 5 Amp for 28 VDC and 250 ~VAC **RESISTIVE** loads. IMPORTANT: Appropriate diode (DC loads) or MOV (AC loads) snubber devices must be installed with inductive loads to prevent RFI noise spikes.

Optional solid state relays are rated at 2 Amp 12-280 ~VAC (600Vpk).

Relay wiring should be kept separate from low level signal wiring.

### 1.2.3 Ambient Temperature Range

-25 to 60 degrees C

### 1.2.4 Humidity Range

0 TO 90% R. H. Non-Condensing.

### 1.2.5 Altitude

Recommended up to 2000 meters

### 1.2.6 Housings / Installation Categories

- NEMA 4X wall mount. DIV 2 Groups A,B,C,D; Category II and pollution degree 3; NEMA 4X; IP66
- NEMA 7 wall mount for DIV 1 & 2 Groups B,C,D; includes 'O' Ring in door to satisfy NEMA 4 rating.
- Includes standard non-intrusive magnetic keypad.

### 1.2.7 Approvals

CSA C22.2 No 1010.1 and ISA S82.02; CSA C22.2 No 152 for combustibles; UL 1604 / C22.2 No 213 (Div 2 Groups A,B,C,D); EN55011 & EN61000 (CE Mark). CSA File # = 252022 and may be seen at: [CSA-International.org](http://CSA-International.org).

# SECTION - 2

## 2.0 Basic Operation

The WX4's graphic LCD displays monitored data and with the 5-button keypad also serves as the system's operator interface. All WX4 configuration variables are entered with this operator interface using SETUP menus accessed by pressing **EDIT** from either data screen. This *Setup* mode may be exited manually by pressing **NEXT**, or automatically when no keys are pressed for 5 minutes. Alarm relays and front panel alarm LED indicators remain active during the *Setup* mode. Alarm LED's flash upon new alarms and become steady after Acknowledged by pressing the **ALARM RESET** key. A **SECURITY** menu offers a password feature to prevent tampering with WX4 parameters.

A "sign-on" screen appears briefly after power is applied that indicates what type input / output options the unit is configured with.

## 2.1 Setup Menu Configuration

Variables inside the **CHANNEL** (see section 2.2) and **SYSTEM** (see section 2.3) menu trees allow WX4 configuration for a wide range of monitoring applications. Select the desired menu by scrolling with **UP/DOWN** and then **EDIT** to enter each menu. Figure 2.0 illustrates the menus tree for configuring *Channel* and *System* specific variables. *Channel* variables affect only the specific channel selected while *System* variables are related to features not specific to any channel.

## QUAD Channel Controller Menu Tree




Figure 2.0

## 2.2 Changing Menu Variables Using the Keypad

Upon entering a menu, a pointer controlled by the **UP/DOWN** keys indicates the selected variable. Some are simple **YES/NO** or **ON/OFF** entries toggled by pressing the **EDIT** key. Others, such as *Channel ID* and *Units* fields may have many ASCII character possibilities. Allowed ASCII characters are as follows:  
 ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^\_`abcdefghijklmnopqrstuvwxyz blank space  
 !"#\$%&'()\*+,-./0123456789;<=>?@. Notice the often used blank character is located

after lower case **z** and before the exclamation point **!**. **EDIT** places a cursor under the item and **UP/DOWN** scrolls through each allowed entry. The **NEXT** key moves the cursor to the next position within a field. When the field is complete, **EDIT** clears the cursor and loads the field into non-volatile memory where it is retained indefinitely. Without a cursor present, the **NEXT** key closes open menus in reverse order and returns the LCD to the data display.

### 2.2.1 WX4 Setup Configuration Menus

The **SETUP** menu shown in the middle of Figure 2.0 and in Figure 2.1 below is reached by pressing **EDIT** with any data display present. This is the entry-level screen to *ALL Channel*, *System* and *Security* menus. It also shows the revision of firmware operating in the WX4. Use the **UP/DOWN** keys to move the pointer to the desired menu and press the **EDIT** key.



Figure 2.1

### 2.2.2 Channel Setup Entry Menu

The CHANNEL menu shown below in Figure 2.2 allows configuration of all variables for the selected channel. These are **Fault**, **Alarm 1**, **Alarm 2**, **Alarm 3**, **Configure** and **CAL Setup**.



Figure 2.2

## 2.2.3 FAULT / ALARM 1 / ALARM 2 / ALARM 3 SET-UP Menus

Alarms 1, 2 and 3 have identical menus. The only difference between each is A1 front panel LED indicators are yellow while A2 and A3 are red. Typical applications often have A1 set at a WARN level, A2 at a HIGH level and A3 at a higher SHUT DOWN level. However, it is important to understand there is no functional difference between A1, A2 and A3, and since their configuration menus are identical, only one is shown in Figure 2.3. The Fault menu is identical to A1, A2, A3 except Fault alarms are always low trips (alarm activates as input goes below the setpoint) and Fault alarms may not be set for latching operation.




Figure 2.3

- **Set Point** is entered in engineering units and determines the value where the alarm trips. For example, if a channel monitors 0-50 ppmH<sub>2</sub>S and the desired alarm level is 10 ppm, the correct entry is 10.00. A one percent dead band prevents alarm chatter. This means after tripping an alarm, the input must move at least 1% of full scale back through the setpoint for the alarm to auto reset.
- The **ON Delay / OFF Delay** entries allow **ON** and **OFF** time delays affecting how long the trip-point must be surpassed before an alarm event transition occurs. **ON** delays are limited to 10 seconds while **OFF** delays may be as long as 120 minutes. Delays are useful in many applications to prevent nuisance alarms and unwanted cycling into and out of alarm conditions.
- **Low Trip** is set for **NO** for increasing alarms or **YES** for decreasing alarms to determine if the alarm activates upon exceeding or falling below the setpoint.
- **Latching** determines either manual or automatic alarm reset operation. **YES** requires a manual **Alarm Reset** to unlatch the alarm even though an alarm condition no longer exists. **YES** also causes this alarm's common relay, front panel LED, and optional discrete relay to latch. **NO** allows all outputs for this alarm to automatically reset after the alarm condition clears.

Common alarm LED indicators on the left side of the front panel indicate the status of A1, A2 A3 alarms. The common Fault LED is on the lower right side



of the front panel. Any *new* alarm event causes the associated LED to flash until an **Alarm Reset** occurs causing an *acknowledged* steady on condition. Operators should recognize *new* alarms by a flashing LED. **Alarm Reset** also *acknowledges*, or deactivates, audible devices driven by the AUDIBLE ALARM option connector J2 (see Figure 3.1).

## 2.2.4 Configure Menu to Define Channel

The channel setup menu after the alarm menus is **CONFIGURE**. It allows setting **Name** and **EUNIT** 10 digit ASCII fields, defines the measurement range with **ZERO** & **SPAN** entries, number of **Decimal Points** of resolution the reading will have, and if the channel is **Active**.



Figure 2.4

### 2.2.4.1 Name / EUNITS ASCII Data Fields

The first two items in this menu are for entering the 10 character channel *Name* and *engineering unit* ASCII fields. *Name* should describe the channel's data in user terminology such as tag # or other description. *Eunits* should define the units of measure for what this channel is to display. Section 2.2 describes how to modify these fields using the keypad.

### 2.2.4.2 Input Measurement Range

The **Zero / Span** menu entries allow configuration of the measurement range displayed by this channel. Measurement Range defines the range of the input signal's engineering units. For example, if a channel's input is 4-20mA from a transmitter monitoring 0 to 10ppm chlorine, then the **Zero** value should equal 0.000 and the **Span** value equal 10.00. Four digits must be entered, so trailing 0's may appear here that are not displayed on other data screens. These menus work hand in hand with Min/Max Raw Counts menus described in section 2.3.4.

### 2.2.4.3 Decimal Point Resolution

Resolution of the displayed channel value is configured in this menu by setting the number digits trailing the decimal point. Displayed readings are limited to a maximum of four digits with a polarity sign. Auto-ranging displays the highest resolution allowed by this menu's decimal point entry. For example, a range of 0 to 100ppm and two decimal points reads **0.00** at 0ppm and **100.0** at 100ppm. This may be undesirable due to the high resolution at zero unless the sensor's output is extremely stable. If decimal points are limited to one, the 0ppm reading becomes **0.0** and the 100ppm reading

remains **100.0**. Resolution may be limited further by setting decimal points to **0** where in the above example, 0ppm reads **0** and 100ppm reads **100**.

#### 2.2.4.4 Turning Off Unused Channels

The **Channel Active?** menu entry asks if this channel is to be utilized. **OFF** causes the controller to never process inputs applied to this channel and no alarms are tripped or data displayed. Inactive channels have a line drawn through them on the Setup screen to indicate it is turned off.

### 2.2.5 Cal Setup Menu

The WX4 CAL MODE feature supports pushbutton calibration of zero and span values. This feature should be utilized only when there are no other zero/span controls within the monitoring system, since it is inappropriate to calibrate a signal at more than one point. Therefore, if calibration will be performed at another transmitter or monitoring device, the WX4 CAL MODE feature should not be used.

The **CAL SETUP** menu allows entering the correct **Zero & Span Gas** setpoint values needed to calibrate the channel. These are entered in the same engineering units as input range.




Figure 2.5

### 2.2.6 Calibrate Input Menu

The CAL MODE (flow chart shown in Figure 2.6) is designed to make calibration quick, easy and error free. A successful ZERO and SPAN calibration requires only a few keystrokes. Optional 4-20mA outputs (if equipped) transmit 1.5mA during CAL MODE and 4mA during the subsequent CAL DELAY to prevent external alarms during calibration. Local WX4 alarm relays are inhibited during CAL MODE. Unintentional calibrations may be reset by the **Set UNITY** menu item. **Set UNITY** resets **Cal OFFSET** to 0 & **Cal GAIN** to 1, which is useful for returning the calibration to a known starting place. Sensor aging may be monitored by recording zero and span readings at **Unity Gain** when the sensor is new, and again later when degradation may have occurred. CAL MODE automatically exits if no keystroke is detected after 5 minutes.

Use the following step-by-step procedure to perform ZERO and SPAN calibrations.

1. To enter the CAL MODE from any data display, press the dual purpose DOWN / CAL key then use the UP/DOWN keys to select the channel to calibrate.

2. Stimulate the monitor to be calibrated with an appropriate ZERO calibration standard. Observe the screen's live reading, and when it is stable, press the EDIT key to perform the ZERO calibration.
3. If the ZERO calibration is successful, CAL MODE automatically proceeds to the SPAN check.
4. Apply the **correct** SPAN calibration standard. After the reading is stable, press the EDIT key to perform a SPAN calibration.  
**WARNING:** The SPAN calibration standard used must match the value specified, since this is the reading the WX4 will indicate after a successful SPAN calibration. The SPAN calibration value may be edited if it becomes necessary to apply a different calibration standard to set SPAN (see **Span Calibration** in section 2.2.5).
5. If the SPAN calibration is successful, the display flashes "REMOVE CAL GAS" and starts the CAL DELAY.
6. CAL MODE will be complete after the end of the CAL DELAY.

The flow chart in Figure 2-6 illustrates the above procedure. **UP, CAL, NEXT & EDIT** labels indicate keystrokes (**CAL/DOWN** is a dual purpose key). The CAL MODE information screen (top of the chart) is available for advanced users to see Offset / Gain calibration constants and live analog to digital converter (A/D) counts. Span setpoint calibration values may also be edited from this screen. Holding the **UP** key for 5 seconds during CAL MODE displays this screen.

**Unity Gain** may be used at any time to cancel incorrect calibrations and start again. Unity means Offset = 0.00 and Gain = 1.00.




Figure 2.6

## 2.3 System Configuration Menus

Several items needing configuration are not specific to either channel but affect the entire WX4 system. These are located in the **SYSTEM** menus group shown in the

dotted line box in Figure 2.0. System menus are accessed through the System SETUP menu shown in Figure 2.7 by pointing to the desired item and pressing EDIT.




Figure 2.7

### 2.3.1 Standard / Optional Relay Setup Menus

The menu shown in Figure 2.8 allows configuring of both the standard **Relay 1 & Relay 2** motherboard relays and the six optional relays on the 10-0222 discrete relay option PCB. Both standard and optional relays are programmed in this menu. Select the relay to be configured by pointing the arrow at the top menu item and pressing EDIT. The field will scroll through all eight possible relays (2 standard and 6 optional).



Figure 2.8

- **Fault, Alarm 1, Alarm 2, Alarm 3** menus in Figure 2.8 offer additional “voting” flexibility by controlling the channel alarm combinations that will trip the selected relay. Each **Votes** entry requires this quantity of channels for each type alarm be active before this relay activates. As illustrated in Figure 2.8 above, Standard Relay 1 activates when *any* 2 channels have Alarm 1 conditions, PLUS, any one channel has an Alarm 2 condition. And since the **Over Ride** menu (see description below) contains the **Ch1A2** entry, Standard Relay 1 also activates if alarm 2 on channel 1 trips. Fault Votes and Alarm 3 Votes values are 0, therefore Fault and Alarm 3 conditions will not affect this relay. Votes follow the logical “AND” function.
- **Failsafe** set for YES causes this relay to be energized when its voting requirements are false (no alarm condition) and de-energized when the alarm vote requirements are true. The primary benefit of **Failsafe** is loss of power places the relay contacts into the alarm condition.

- “**Over Ride**” menu allows entering one of the 16 different alarms that will trip this relay regardless of the **Votes** entries. There are four alarms per channel and four channels, and any one of these alarms may be used as the Over Ride. This feature is useful when one channel's alarm has more significance than the others.

### 2.3.2 Relay 2 ACK (Acknowledge) / Horn Setup Menu

- The **Horn SETUP** menu controls how each alarm type (Fault, and Alarms 1 through 3) will affect the horn driver circuit connected to J2 on the motherboard. Choices are **OFF**, **STEADY** or **PULSE**. Warning level alarms might be set to pulse the horn, with high alarms set for steady. Personnel then know which alarm level is present by hearing the pulsing or steady horn.
- **Relay 2 Acknowledge** set to **ON** allows Relay 2 to be deactivated during alarm conditions by an **Alarm Reset**. This is useful if another audible device is being driven by the relay. The acknowledge feature is not available for Relay 1, since it is often used for driving a warning light and Relay 2 for driving a horn. It could be dangerous if an operator acknowledged the horn AND the light since no indication of the high alarm condition remains.
- **Local Piezo** set to **ON** causes the tiny local piezo adjacent to the LCD to mimic the J2 horn output.



Figure 2.9

### 2.3.3 Clock / Delays Menu

These WX4 timers accommodate inputs that may require varying times to stabilize after power is applied and after calibrations are complete.

- **Alarm Refresh** menu allows reactivation of *Acknowledged* alarms after the time period expires. This feature is used primarily to restart audible alarm devices after having been silenced by an acknowledge function (via serial port or pressing the Alarm Reset button). An entry of 0 seconds effectively disables the **Alarm Refresh** function.
- **Warm Up Delay** menu allows setting how long alarm relays remain disabled after power is applied.
- **Cal Delay** determines how long alarm relays are inhibited after completing a calibration.

- **Time** and **Date** menu items are for setting the correct time and date. The WX4 is equipped with a 24-hour clock and calendar. Time of day must be entered in 24-hour mode. For example, 6:00:00 PM = is indicated as 18:00:00.




Figure 2.10

### 2.3.4 Communications Menu

The **COMM SETUP** menu allows setting of the system's ModBus **Slave ID** or RTU address (requires 10-0253 ModBus option PCB – see Section 3.2). This slave port may be used to transfer WX4 data to a ModBus *master* device such as a PC, PLC, DCS or even other Oldham WX-Series Controllers such as the 16 Channel WX16. The slave port is addressable, allowing many WX4 controllers to be connected to a single RS-485 cable. A converter is available to make this port also compatible with Ethernet TCP/IP networks.

The entire ModBus database, including registers and supported Function Codes, is documented in section 3.2.1. See section 4 for **COMM SETUP** menu descriptions for **WIRELESS** WX4 networks.




Figure 2.11

### 2.3.5 Analog Setup Menu

The system **ANALOG SETUP** menus in Figure 2.12 allow setting the 11-bit A/D (analog to digital) counts and the 10-bit D/A (digital to analog) counts for each of the four channels. Use the Set Channel entry to scroll to the desired channel using the EDIT key. The live A/D counts value for the channel selected is also shown on the bottom of this screen.

The default setting for A/D counts is 400 for Min and 2000 for Max. This is based upon a 0-20mA input providing 0-2000 counts, or, 100 counts per mA input.

Min Counts / Max Counts entries in the INPUT SETUP menus define the input A/D counts range for Zero and Span readings as described in section 2.2.4b. The default settings for each analog channel are 400 to 2000 counts. Standard inputs yield 400 counts at 4mA and 2000 counts at 20mA but, for example, if a special application requires the Zero reading at 6mA input and the Span reading at 18mA input the correct A/D Min / Max Raw counts would be 600 to 1800.00.

Min Counts / Max Counts entries in the OUTPUT SETUP menus define the output D/A counts range for Zero and Span readings as described in section 2.2.4b. OUTPUT SETUP menus are only used when the WX4 is equipped with the 10-0308 4-20mA output option (Section 3.1.5). Ideally, 200 to 1000 yields a 4-20mA output but very slight modifications may be needed to provide precise 4mA and 20mA values for each channel.




Figure 2.12

## 2.4 System Security Menu

A 4-digit **Pass Code** entered and confirmed in this menu item locks all menus. *Viewing* menus is not denied, but attempts to *edit* variables flashes the **Locked** message on the LCD.

Authorized individuals locking the system should first enter a name, phone #, or other contact information into the 12 character field on the top line of the Security screen. To lock or unlock the system, the correct 4 digit authorization number must be entered into the **Pass Code** field. It is very important to remember the 4 digit code, since the factory must be consulted if it is lost.



Figure 2.13



# SECTION - 3

## 3.0 Motherboard Interface PCB #10-0215

The WX4 motherboard shown below in Figure 3.1 is the interface between the Display/CPU assembly and all other system I/O devices. The Display/CPU assembly attaches to the motherboard with 4-standoffs and connects via ribbon cable to S1. Input options described in sections 3.1.1 and 3.1.2 are available that may be installed into the *Input Option* P1 connector located on the lower left side of the motherboard. The middle position P2 connector is for the 10-0308 4-20mA Output option and the right position P3 connector is for the 10-0222 Discrete Relay option. Other option devices such as ModBus RTU RS-485, Ethernet and a data logger may also be installed to connectors located on the motherboard.

The motherboard PCB contains a 24 VDC universal input (100-240 VAC) switching power supply with up to 350mA available at the TB3 Auxiliary Power Output terminals. If AC power is unavailable, or if a DC battery back-up supply is needed, TB1 provides terminals for DC power input. Blocking diodes isolate internal and external DC supplies as shown in Figure 3.0. See section 1.2.1 for additional power source information.




Figure 3.0

TB2 offers field terminals for a remote alarm reset switch. The motherboard also includes standard alarm relays 1 & 2 (K1 & K2) and their indicating LED's. TB4 provides field wiring terminals for these relays. TB5 is for connection to the 100-240 VAC power source. J2 is a 2-pin connector for powering the optional part #1000-1892 audible annunciator.




Figure 3.1

## 3.1 Input / Output Optional PCBs

P1, P2 and P3 connectors on the motherboard offer unique positions for I/O options described in this section. A screen appears briefly after power-up indicating what I/O options are connected. The P1 position accepts either the 10-0221-4 Analog Input option or the 10-0309 Bridge Sensor Input option. Both have default **Input Min / Max** menu (see section 2.3.4) settings of 400 – 2000 counts.

P2 is reserved only for the 10-0308 4-20mA Output option and P3 is reserved only for the 10-0222 Discrete Relay option. Connector locations, relative to each option's mounting screws, prevent incorrect installation.

### 3.1.1 Optional Analog Input PCB #10-0221-4

**Important!** 10-0221-4 PCB's may only be installed into motherboard position P1.

Analog input PCB option #10-0221-4, shown in Figure 3.2 allows interfacing WX4's to field transmitters having 4-20mA or voltage outputs. Remove socketed 100 ohm (R1 – R4) terminators for 0-4 VDC max voltage inputs. The 10-0221-4 utilizes a 12-bit A/D converter such that 4mA provides 400 counts and 20mA 2000 counts. Min/Max raw counts menus default to 400/2000, but may be adjusted between 0/4095 as described in the **A/D Min / Max Raw** discussion in section 2.3.4. TB1 & TB2 provide each channel's terminals for receiving analog inputs. TB1 & 2 also provides 4 terminals connected to the WX4 internal 24 VDC power supply for powering external transmitters. Figure 3.3 shows correct wiring for both 2-wire and 3-wire transmitters.

\*R1 = Ch1 100 ohm 4-20mA terminator

\*R2 = Ch2 100 ohm 4-20mA terminator

\*R3 = Ch3 100 ohm 4-20mA terminator

\*R4 = Ch4 100 ohm 4-20mA terminator

\*Spare = Spare 100 ohm 4-20mA terminator

\* These 5 resistors are socketed for easy replacement.

Terminators are connected between each channel's HI & LO terminals.

LO = 24VDC Power Supply Common

24VDC = 24VDC Power Supply + output




Figure 3.2




Figure 3.3

### 3.1.2 Optional Bridge Sensor Input Board #10-0309

**Important!** 10-0309 PCB's may only be installed into motherboard position P1.

The 10-0309 Quad Channel *Bridge Sensor Input* option shown in Figure 3.4 allows these popular sensors to be connected directly to the WX4 without additional signal conditioning or transmitters. Each channel is equipped with a bridge amplifier, balance potentiometer, and an adjustable switching regulator for setting the correct sensor excitation voltage. A 3 position coarse gain jumper allows setting the gain of the bridge

amplifier. Fault supervision circuitry forces the WX4 into a FAULT condition upon sensor failure or removal.

This option may also be configured to accept 4-20mA inputs into channels 3 & 4 to allow mixing sensors and current loops into the same board. Placing either channel's 2 position LEL/4-20mA jumper (JP5 or JP6) into the 4-20mA position, and installing the associated precision 100 ohm socketed resistor, allows 4-20mA signals to be applied to the mA+ / mA- terminals (see *Optional 4-20mA* notes in Figure 3.4). Precision 100 ohm resistors are taped to the inside of the WX4 enclosure.

Bridge sensors require the **Initial Setup** calibration procedure described in section 3.1.3. After performing the one time only Initial Setup, all subsequent calibrations are by the WX4's electronic Cal Mode menus (see section 2.2.5). Sensors mounted locally to the WX4 normally do not require **Initial Setup**, since it is performed at the factory.

### 3.1.3 Bridge Sensor Initial Setup

Bridge sensors vary widely in power requirements and sensitivity. It is therefore important to configure each channel to match the sensor with which it will operate.

1. Prior to connecting remote sensors, apply power to the system. Measure the voltage between each channel's A and R terminals and set the *Voltage Adjust* potentiometers for the correct sensor excitation voltage (remove WX4 terminal cover). This may range from 1.5 volts to 7.5 volts depending upon sensor specifications. ***Sensors may be damaged by accidental over voltage conditions. It is recommended the Voltage Adjust potentiometer screws be covered by a dollop of RTV or similar material after completion of this procedure.***
2. Remove system power and connect sensor wires to the A-C-R terminals. Reapply system power and confirm correct voltage across each sensor's A & R terminals. Note if sensor wires are long, it will be necessary to measure the excitation voltage at the sensor end to compensate for  $I \cdot R$  voltage losses in the wiring.
3. With zero cal stimulus on that sensor, adjust its *Balance* potentiometer for a ZERO reading on the LCD.
4. Apply 50% span stimulus to the sensor and allow the reading to stabilize. Place the 3 position *Coarse Gain* jumper into the position which reads between approximately 45 and 65% with 50% on the sensor. Gain settings for each jumper position are as follows: no jumpers = 1, **LO** = 7, **MED** = 12, **HI** = 24. Multiple jumpers have an additive affect upon gain, so for example the **LO** and **MED** jumpers together provide a gain of 19.

Initial setup is now complete and normally only requires repeating if a sensor is replaced. **Final calibration of this channel may now be performed using the WX4's electronic Cal Mode feature described in section 2.2.5.**




Figure 3.4

### 3.1.4 Optional Discrete Relay PCBs #s 10-0222


**Important!** 10-0222 PCBs may only be installed into motherboard position P3.

The optional *Discrete Relay PCB*, shown in Figure 3.5, adds six 5 amp form C relays. Each relay is fully programmable as described in section 2.3.1. Many WX4 applications utilize the standard equipped Relay 1 / Relay 2 (see section 2.3.1) and do not require optional discrete relays



All mechanical (dry contact) relays are rated at 5 Amp for 28 VDC and 250 ~VAC **RESISTIVE** loads. **IMPORTANT:** Appropriate diode (DC loads) or MOV (AC loads) snubber devices must be installed with inductive loads to prevent RFI noise spikes.

AC or DC power supplies to relays on the 10-0222 Discrete Relay PCB option must be the same for each relay. Example: 24 VDC should not be the power switched by one relay and 115 VAC by others.



**Note:**  
When installed, this option blocks access to the fuse and must be removed to replace a blown fuse.

**WARNING:** For continued protection against fire replace only with same type and rating of fuse.

K1, K2, K3, K4, K5 & K6 are programmable as described in Section 2.3.1.

TB1 terminals 1,4,7,10,13 & 16 are Normally Open Contacts for K1-K6

TB1 terminals 2,5,8,11,14 & 17 are Normally Closed Contacts for K1-K6

TB1 terminals 3,6,9,12,15 & 18 are Common (pole) Contacts for K1-K6

Contacts are rated for 5 amp resistive loads. Arc suppressing snubber devices should be used for switching inductive loads.

Figure 3.5

### 3.1.5 Optional 4-20mA Analog Output Board #10-0308

**Important!** 10-0308 PCB's may only be installed into motherboard position P2.

An optional 10-bit 4-20mA analog output board, shown in Figure 3.6, may be added. Each channel's output will transmit 4mA for 0% readings and 20mA for 100% readings. If the WX4 primary power is 100 – 240 VAC or at least 24 VDC, 4-20mA outputs are capable of driving 20mA through a 750 ohm load. Outputs are self powered and DC power should not be provided by the receiving device. Precision calibration of the 4-20mA output DAC (digital to analog converter) is accomplished via the **Analog Setup** menu as described in section 2.3.4.




Figure 3.6

## 3.2 ModBus RS-232 / RS-485 Interface Option #10-0253

The 10-0253 ModBus option PCB add both RS-232 and RS-485 ModBus RTU slave ports. Figure 3.7 shows this optional PCB, which mounts to connectors on the upper left corner of the WX4 motherboard. TB1 provides two pairs of T/Rx terminals and a floating terminal for shield continuation. This makes it easy to multi-drop WX4's onto an RS-485 cable without doubling wires into the same screw terminals. RS-232 interface may be made by connecting to DB9 connector S1. Section 3.2.1 lists all ModBus registers and their function codes.



Follow correct IEEE RS-232 and RS-485 installation guidelines when using the 10-0253 option.






Figure 3.7

### 3.2.1 ModBus Register And Function Code Summary

The following table identifies the available ModBus RTU register locations and function codes.

Variable	Alias	Read Function Code	Write Function Code
<b>Read/Write Coils:</b>			
Alarm Ack/Reset	2001	1	5
<i>Note: After writing a TRUE to this register, the WX4 automatically returns it to FALSE.</i>			
<b>Read Only Discrete:</b>			
Chan 1 Fault Alarm	12001	2	NA
Chan 1 Alarm 1	12002	2	NA
Chan 1 Alarm 2	12003	2	NA
Chan 1 Alarm 3	12004	2	NA
Chan 2 Fault Alarm	12005	2	NA
Chan 2 Alarm 1	12006	2	NA
Chan 2 Alarm 2	12007	2	NA
Chan 2 Alarm 3	12008	2	NA
Chan 3 Fault Alarm	12009	2	NA
Chan 3 Alarm 1	12010	2	NA
Chan 3 Alarm 2	12011	2	NA
Chan 3 Alarm 3	12012	2	NA
Chan 4 Fault Alarm	12013	2	NA
Chan 4 Alarm 1	12014	2	NA
Chan 4 Alarm 2	12015	2	NA
Chan 4 Alarm 3	12016	2	NA
Standard Relay 1	12017	2	NA
Standard Relay 2	12018	2	NA
Optional Relay 1	12019	2	NA
Optional Relay 2	12020	2	NA
Optional Relay 3	12021	2	NA
Optional Relay 4	12022	2	NA
Optional Relay 5	12023	2	NA

Variable	Alias	Read Function Code	Write Function Code
Optional Relay 6	12024	2	NA
Input Fault Relay	12025	2	NA
<b>Read Only Registers:</b>			
Product ID	30001	4	NA
<i>Returns the numeric value "1000" for product ID.</i>			
Firmware value	30002	4	NA
<i>Return a numeric value for firmware value as (Version divided by 100).</i>			
D2A Chan 1	31001	4	NA
D2A Chan 2	31002	4	NA
D2A Chan 3	31003	4	NA
D2A Chan 4	31004	4	NA
<i>12 bit value representing the D2A value of 800 (0%) to 4000(100%) after all cal features are applied.</i>			
Chan 1 Status	31005	4	NA
Chan 2 Status	31006	4	NA
Chan 3 Status	31007	4	NA
Chan 4 Status	31008	4	NA
<b>16 bit status word bit assignment for each channel.</b>			
ALARM1_BELOW_BIT	BIT1		
ALARM2_BELOW_BIT	BIT2		
ALARM3_BELOW_BIT	BIT3		
ALARM1_LATCH_BIT	BIT5		
ALARM2_LATCH_BIT	BIT6		
ALARM3_LATCH_BIT	BIT7		
WIRELESS INPUT	BIT4		
CHANNEL_DISABLED_BIT	BIT9		
CHANNEL_CAL_BIT	BIT10		
System Status Word	31009	4	NA
<b>16 bit status word bit assignment for system status.</b>			
TRACK NEGATIVE	BIT0		
WIRELESS RECEIVER	BIT1		
SECURITY LOCK	BIT15		
Alarm Status Word	31010	4	NA
<b>16 bit status word bit assignment for system status.</b>			

Variable	Alias	Read Function Code	Write Function Code
CHAN1 FAULT	BIT0		
CHAN1 ALARM1	BIT1		
CHAN1 ALARM2	BIT2		
CHAN1 ALARM3	BIT3		
CHAN2 FAULT	BIT4		
CHAN2 ALARM1	BIT5		
CHAN2 ALARM2	BIT6		
CHAN2 ALARM3	BIT7		
CHAN3 FAULT	BIT8		
CHAN3 ALARM1	BIT9		
CHAN3 ALARM2	BIT10		
CHAN3 ALARM3	BIT11		
CHAN4 FAULT	BIT12		
CHAN4 ALARM1	BIT13		
CHAN4 ALARM2	BIT14		
CHAN4 ALARM3	BIT15		
LED Blink Status	31011	4	NA
<i>Bit set to 1 = LED Blinking, bit set to 0 = LED is steady ON.</i>			
CHAN1 FAULT	BIT0		
CHAN1 ALARM1	BIT1		
CHAN1 ALARM2	BIT2		
CHAN1 ALARM3	BIT3		
CHAN2 FAULT	BIT4		
CHAN2 ALARM1	BIT5		
CHAN2 ALARM2	BIT6		
CHAN2 ALARM3	BIT7		
CHAN3 FAULT	BIT8		
CHAN3 ALARM1	BIT9		
CHAN3 ALARM2	BIT10		
CHAN3 ALARM3	BIT11		
CHAN4 FAULT	BIT12		
CHAN4 ALARM1	BIT13		

Variable	Alias	Read Function Code	Write Function Code
CHAN4 ALARM2	BIT14		
CHAN4 ALARM3	BIT15		
Relay Status	31012	4	NA
<i>Note: 1 = energized; 0 = deenergized</i>			
STANDARD RELAY 1	BIT0		
STANDARD RELAY 2	BIT1		
OPTION RELAY 1	BIT2		
OPTION RELAY 2	BIT3		
OPTION RELAY 3	BIT4		
OPTION RELAY 4	BIT5		
OPTION RELAY 5	BIT6		
OPTION RELAY 6	BIT7		
COMMON FAULT (no relay)	BIT8		
Reserved	BIT9		
Reserved	BIT10		
Reserved	BIT11		
Reserved	BIT12		
Reserved	BIT13		
Reserved	BIT14		
Reserved	BIT15		

Variable	Alias	Read Function Code	Write Function Code
<b>Memory Reals:</b>			
<i>Notes: 41001 – 41040 “Real” represents float value without the decimal point such that 123.4 is returned as 1234. Decimal divisor is returned as 1, 10, 100, or 1000 for decimal position of 1, 2, 3, or 4, where 123.4 would return the divisor value 10.</i>			
Chan 1 Zero Real	41001	3	NA
Chan 1 Zero Divisor	41002	3	NA
Chan 1 Span Real	41003	3	NA
Chan 1 Span Divisor	41004	3	NA
Chan 1 Fault Alarm Real	41005	3	NA
Chan 1 Fault Alarm Divisor	41006	3	NA

Variable	Alias	Read Function Code	Write Function Code
Chan 1 Alarm 1 Real	41007	3	NA
Chan 1 Alarm 1 Divisor	41008	3	NA
Chan 1 Alarm 2 Real	41009	3	NA
Chan 1 Alarm 2 Divisor	41010	3	NA
Chan 1 Alarm 3 Real	41011	3	NA
Chan 1 Alarm 3 Divisor	41012	3	NA
Chan 2 Zero Real	41013	3	NA
Chan 2 Zero Divisor	41014	3	NA
Chan 2 Span Real	41015	3	NA
Chan 2 Span Divisor	41016	3	NA
Chan 2 Fault Alarm Real	41017	3	NA
Chan 2 Fault Alarm Divisor	41018	3	NA
Chan 2 Alarm 1 Real	41019	3	NA
Chan 2 Alarm 1 Divisor	41020	3	NA
Chan 2 Alarm 2 Real	41021	3	NA
Chan 2 Alarm 2 Divisor	41022	3	NA
Chan 2 Alarm 3 Real	41023	3	NA
Chan 2 Alarm 3 Divisor	41024	3	NA
Chan 3 Zero Real	410251	3	NA
Chan 3 Zero Divisor	41026	3	NA
Chan 3 Span Real	41027	3	NA
Chan 3 Span Divisor	41028	3	NA
Chan 3 Fault Alarm Real	41029	3	NA
Chan 3 Fault Alarm Divisor	41030	3	NA
Chan 3 Alarm 1 Real	41031	3	NA
Chan 3 Alarm 1 Divisor	41032	3	NA
Chan 3 Alarm 2 Real	41033	3	NA
Chan 3 Alarm 2 Divisor	41034	3	NA
Chan 3 Alarm 3 Real	41035	3	NA
Chan 3 Alarm 3 Divisor	41036	3	NA

Variable	Alias	Read Function Code	Write Function Code
Chan 4 Zero Real	41037	3	NA
Chan 4 Zero Divisor	41038	3	NA
Chan 4 Span Real	41039	3	NA
Chan 4 Span Divisor	41040	3	NA
Chan 4 Fault Alarm Real	41041	3	NA
Chan 4 Fault Alarm Divisor	41042	3	NA
Chan 4 Alarm 1 Real	41043	3	NA
Chan 4 Alarm 1 Divisor	41044	3	NA
Chan 4 Alarm 2 Real	41045	3	NA
Chan 4 Alarm 2 Divisor	41046	3	NA
Chan 4 Alarm 3 Real	41047	3	NA
Chan 4 Alarm 3 Divisor	41048	3	NA
<b>Memory ASCII Strings:</b>			
User Info Chan 1	40401-40405	3	NA
User Info Chan 2	40406-40410	3	NA
User Info Chan 3	40411-40415	3	NA
User Info Chan 4	40416-40420	3	NA
<i>10 ASCII characters (2 per register) assigned to the unit identifier read as bytes.</i>			
EUNITS Chan 1	40421-40425	3	NA
EUNITS Chan 2	40426-40430	3	NA
EUNITS Chan 3	40431-40435	3	NA
EUNITS Chan 4	40436-40440	3	NA
<i>10 ASCII characters (2 per register) assigned to the engineering units read as bytes.</i>			
Chan 1 ASCII Reading	40441-40443	3	NA
Chan 2 ASCII Reading	40444-40446	3	NA
Chan 3 ASCII Reading	40447-40449	3	NA
Chan 4 ASCII Reading	40450-40452	3	NA
<i>6 ASCII characters (2 per register) reflecting the display readout.</i>			
<b>Firmware Version:</b>			
Version	40453-40455	3	NA
<i>4 ASCII characters (2 per register) reflecting the firmware version.</i>			

### 3.3 Optional 24 VDC 50 Watt Power Supplies

Many applications require 24 VDC power in excess of the 12 watts supplied by the PS1 power supply located on the motherboard (see Figure 3.1). "Extended" enclosure models (see Section 4) may be equipped with an integral 1000-2259 NEC Class 2 FIFTY WATT supply are available for Division 1 (part #10-0314) and Division 2 (part #10-0315) potentially hazardous area installations and both also include a NEMA 4X weather rating. See addition details at [www.oldhamgas.com](http://www.oldhamgas.com).



# SECTION - 4

## 4.0 NEMA 4x Polycarbonate Wall Mount (Extended)

The WX4 wall mount NEMA 4X enclosure is shown in Figure 4.0. Non-metallic enclosures are not grounded by metal conduit. For internal ground points to be grounded to earth, the TB5 – GND terminal must have a proper earth ground connection (see Figure 3.1).



CAUTION: NONMETALLIC ENCLOSURE DOES NOT PROVIDE GROUNDING BETWEEN CONDUIT CONNECTIONS. USE GROUNDING TYPE BUSHINGS AND JUMPER WIRES. ALL FIELD WIRING MUST HAVE INSULATION SUITABLE FOR AT LEAST 250V.




Figure 4.0

### 4.1 NEMA 4 Painted Steel Wall Mount (Extended)

The WX4 shown in Figure 4.1 is a Painted Carbon Steel NEMA 4 wall mount enclosure designed for non-corrosive installations.




Figure 4.1

# 4.2 NEMA 4x Stainless Steel Wall Mount (Extended)

The WX4 shown in Figure 4.2 is a 316 Stainless Steel NEMA 4X wall mount enclosure designed for corrosive installations.




Figure 4.2

### 4.3 NEMA 7 Explosion-Proof Wall Mount (Extended)

The WX4 shown in Figure 4.3 is an aluminum NEMA 7 wall mount enclosure designed for mounting into potentially hazardous installations.




Figure 4.3

# SECTION - 5

## 5.0 Adding the “Wireless” Radio Kit Option

WX4 *slave* serial port may be connected to a FHSS (Frequency Hopping Spread Spectrum) wireless radio modem shown in Figure 5.1. There are two different frequency options offered, 900 MHz (10-0328) and 2.4 GHz (10-0355). The radio kit options allow two separate modes of wireless operation. These are “Wireless Receiver” (section 5.2) accepting data from OLCT 200 wireless transmitters, “Wireless ModBus Slave” (section 5.3) providing data to a ModBus *master* (*master* side of network requires additional radio).

Each transceiver on a wireless network must have its **RADIO SETUP** menus configured to share the same hopping channel (0-32) and System ID (0-255) to communicate. All Oldham WX-Series wireless transceivers utilize a Server-Client network where Clients synchronize their hopping to the Server. The Server transmits a beacon at the beginning of every hop (50 times per second). Client transceivers listen for this beacon, and upon hearing it, will indicate **InRange** with the LED on the radio modem board and synchronize their hopping with the Server. Each network should consist of only one Server. There should never be two servers on the same RF Channel number in the same coverage area, as the interference between the two servers will severely hinder RF communications. The Server must be in a powered location (as opposed to a battery powered OLCT 200 utilizing a “sleep” mode) and Servers typically should be centrally located, since all Clients must receive the beacon in order to communicate.





Figure 5.1

## 5.1 Radio Setup Menu

Radio modules must be connected to the WX4's radio option board for **RADIO SETUP**. Pressing the EDIT key with the arrow pointing to the **Communications** menu brings the **COMM SETUP** menu to the screen. With the arrow pointing at **Configure Radio**, press enter again to enter the **RADIO SETUP** menu (Figure 5.2).

- **Hop Channel** may be set from 1-32 using the WX4 keypad and assigns the pseudo-random radio frequency hopping pattern. A transceiver will not go **InRange** of or communicate with a transceiver operating on a different Hop Channel.
- **System ID** may be set from 1-255 using the WX4 keypad and is similar to a password character or network number and makes network eavesdropping more difficult. A transceiver will not go **InRange** of or communicate with a transceiver operating on a different System ID.
- **Mode** may be set for **CLIENT** or **SERVER**. For a single WX4 communicating to up to four battery powered OLCT 200 transceivers, Mode must = Server. To prolong battery life, wireless OLCT 200's sleep most of the time and therefore may not be Servers. If an application calls for multiple WX4 locations, only one may be set for Server and all others must be Clients. This single Server transmits a beacon that all of the network's Clients synchronize to. **ONLY ONE SERVER PER NETWORK**.



Radio configuration menu only displayed with  
RF module present on motherboard

Figure 5.2

## 5.2 Wireless Receiver Mode

**Wireless Receiver** mode is exclusively for wireless communication to the Oldham OLCT 200 wireless sensor transmitters. In Receiver mode, the radio connects to the WX4's Mother board and receives input data from up to four OLCT 200 wireless transmitters. Wired and wireless inputs may be mixed between the WX4's four channels, so it is possible to also accept wired signals from analog input option PCBs described in section 3.1.

Use the **WIRELESS** setting shown at right of Figure 5.3 ONLY FOR COMMUNICATION TO OLCT 200 WIRELESS TRANSCIVERS.

OLCT 200's transmit 200 counts for 0% and 1000 counts for 100% full scale readings so **Input Min/Max** menu values should be 200 & 1000 (factory default). The **Rmt Xmitter ID** menu entry must match the **Remote ID** address setting in the OLCT 200 providing data to this WX4 channel. Voltage level of the 3.6 volt lithium battery in this OLCT 200 is also displayed on the **ANALOG SETUP** screen, below the Rmt Xmitter ID.




Figure 5.3

### 5.2.1 Radio Status Alarms – Wireless Receiver Mode

When an WX4 channel's Input Type is set for WIRELESS, in addition to processing the OLCT 200's 10-bit "counts" value, it also receives status bits indicating Communications Error, Low Battery and C.

- **Communications Error** – Each channel's 30-minute trend screens (Figure 5.4) are very useful for diagnosing wireless problems, since they indicate amount of time since the most recent transmission was received. The down arrow on top of the trend screen resets to far right each time a transmission is received by that channel. When not in alarm, wireless OLCT 200's transmit each 5 minutes, so the arrow should never progress past the 5-minute interval. The WX4 activates the channel's FAULT alarm and indicates *ComErr* if no transmission has been received in 18 consecutive minutes.
- **Low Battery** status indicates the wireless OLCT 200's integral 3.6V lithium D cell (part #10-0293) has dropped to below 3.3V and should be replaced very soon. *LoBatt* is indicated on the WX4's LCD readout and the Alarm 3 LED flashes. Relays are not energized by low battery conditions. The actual battery voltage of each wireless OLCT 200 may be seen in the **ANALOG SETUP** screen described above in section 5.2.
- **Calibrations** performed at the wireless OLCT 200 force a transmission of the Calibration bit which is indicated on the WX4's LCD readout by "**Rmt Cal.**" Alarms are inhibited until the Calibration bit is cleared.




Figure 5.4

## 5.3 Wireless ModBus Slave Mode

**Wireless MODBUS** allows one or many WX4s to function as wireless ModBus *slaves* by selecting **wireless MODBUS** in the **COMM SETUP** menu (Figure 5.3). These wireless networks require a ModBus *master* such as a DCS, HMI, or other Oldham WX-Series Controller; also equipped with a radio modem. As in all WX-Series wireless networks, one transceiver must be designated as Server and all others as Clients. No special configuration is required by the *master* or *slave* since this is a standard ModBus network. However, radios must have the same **Hop Channel** and **System ID** settings to communicate.

The entire WX4 ModBus database, including registers and supported Function Codes, is documented in section 3.2.1.

## 5.4 Antenna Selection

### 5.4.1 Dipole and Collinear Antennas

These antennas are connected to the Radio via a length of coax cable. If the cable is larger than 6mm diameter (1/4 inch), do not connect the cable directly to the radio connection on the WX4 enclosure. Thick cables have large bending radii, and sideways force on the connector can cause a poor connection. Use a short flexible pigtail (such as our 1000-2308) between the thick cable and the radio connection.

The polarity of these antennas is the same as the main axis, and they are normally installed vertically. They can be mounted horizontally (horizontal polarity), however the antenna at the other end of the wireless link would need to be mounted perfectly parallel for optimum performance. This is very difficult to achieve over distance. If the antenna is mounted vertically, it is only necessary to mount the other antennas vertically for optimum “coupling” – this is easy to achieve.

Dipole and collinear antennas provide best performance when installed with at least 1 to 2 “wavelengths” clearance of walls or steelwork. The wavelength is based on the frequency:

Wavelength in meters = 300 / frequency in MHz



Wavelength in feet = 1000 / frequency in MHz

Therefore, 900 MHz antennas require at least 2/3 meter (2 feet) and 2.4GHz 15 cm (6 inches). Antennas may be mounted with less clearance, but radiation will be reduced. If the radio path is short, this won't matter. It is important the antenna mounting bracket be well connected to "earth" or "ground" for good lightning surge protection.

### 5.4.2 Yagi Antennas

Yagi antennas are directional along the central beam of the antenna. The folded element is toward the back, and the antenna should be "pointed" in the direction of the transmission. Yagis should also be mounted with at least 1 to 2 wavelengths of clearance from other objects. The polarity of the antenna is the same as the direction of the orthogonal elements. For example, if the elements are vertical, the Yagi transmits with vertical polarity.

In networks spread over wide areas, it is common for a central unit to have an omni-directional antenna and the remote units to have Yagi antennas. In this case, as the omni-directional antenna will be mounted with vertical polarity, then the Yagi's must also have vertical polarity. Care needs to be taken to ensure the Yagi is aligned correctly to achieve optimum performance.

Two Yagis can be used for a point-to-point link. In this case they can be mounted with the elements horizontally to give horizontal polarity. There is a large degree of RF isolation between horizontal and vertical polarity (approx -30dB), so this installation method is a good idea if there is a large amount of interference from another system close by transmitting vertical polarity.

An important mounting tip: If a Yagi has drainage holes in the dipole element, do not mount the antenna with the drainage.

### 5.4.3 Mounting Near Other Antennas

Avoid mounting your network's antenna near any other antenna even when the other antenna is transmitting on a different radio band. High RF energy of the transmission from a close antenna can "deafen" a receiver. This is a common cause of problems with wireless systems.

Because antennas are designed to transmit parallel to the ground rather than up or down, vertical separation between antennas is a lot more effective than horizontal separation. If mounting near another antenna cannot be avoided, mounting it beneath or above the other antenna is better than mounting beside it. Using different polarity to the other antenna (if possible) will also help to isolate the RF coupling.

### 5.4.4 Coax Cables

If a coax cable connects to the antenna via connectors, it is very important to weatherproof the connection using our 1000-2314 or equivalent sealing tape. Moisture ingress into a coax cable connection is the most common cause of problems with antenna installations. A three layer sealing process is recommended – an initial layer of electrical PVC tape, followed by a second layer of self-vulcanizing weatherproofing tape (1000-2314), with a final layer of electrical PVC tape.

Allowing a drip “U loop” of cable before the connection is also a good idea. The loop allows water to drip off the bottom of the U instead of into the connection, reduces installation strain and provides spare cable length in case later the original connectors need to be removed, the cable cut back and new connectors fitted.

Avoid installing coax cables together in long parallel paths. Leakage from one cable to another has a similar effect as mounting an antenna near another antenna.

## 5.5 Surge Protection and Grounding

Voltage surges can enter the WX4 via the antenna connection, power supply connection, connections to other equipment and even the “earth” or “ground” connection. Surges are electrical energy following a path to earth, and the best protection is achieved by “draining” the surge energy to earth via an alternate path. Wireless devices need to have a solid connection to earth via a ground stake or ground grid if the soil has poor conductivity. Solid connection means a large capacity conductor (not a small wire) with no coils or sharp bends. All other devices connected to the WX4 need to be grounded to the same ground point. There can be significant resistance between different ground points leading to very large voltage differences during lightning activity. As many wireless units are damaged by earth potential surges due to incorrect grounding as are damaged by direct surge voltage.

It is very difficult to protect against direct lightning strikes, but the probability of a direct strike at any one location is very small. Unfortunately, power line surges and electromagnetic energy in the air can induce high voltage surges from lightning activity several miles away.

### 5.5.1 Antenna Grounding

Electromagnetic energy in the air will be drained to ground via any and every earth path. An earth path exists between the antenna and the WX4, and to protect against damage, this earth path current must be kept as small as possible. This is achieved by providing better alternative earth paths. It is important to ground the antenna to the same ground point as the WX4. Antennas are normally mounted to a metal bracket that should be grounded to the WX4 earth connection. Surge energy induced into the antenna will be drained first by the mount’s ground connection, second by the outside shield of the coax cable to the ground connection on the radio and third by the internal conductor of the coax cable via the radio electronics. This third earth path causes damage unless the other two paths provide a better earth connection allowing surge energy to bypass the electronics.

When an antenna is located outside of a building and outside of an industrial plant environment, external coax surge diverters are recommended to further minimize the effect of surge current in the inner conductor of the coax cable.

Coax surge diverters have a gas-discharge element which breaks down in the presence of high surge voltage and diverts any current directly to a ground connection. A surge diverter is not normally required when the antenna is within a plant or factory environment, as the plant steelwork provides multiple parallel ground paths and good earthing will provide adequate protection without a surge diverter.

## 5.5.2 Connections to Other Equipment

Surges can enter the wireless unit from connected devices, via I/O, serial or Ethernet connections. Other data devices connected to the wireless unit should be well grounded to the same ground point as the wireless unit.

Special care needs to be taken where the connected data device is remote from the wireless unit requiring a long data cable. As the data device and the wireless unit cannot be connected to the same ground point, different earth potentials can exist during surge conditions.

There is also the possibility of surge voltages being induced on long lengths of wire from nearby power cables. Surge diverters can be fitted to the data cable to protect against surges entering the wireless unit.

The same principle applies when the I/O device is not close to the wireless unit, thus, the risk of surge increases. Surge diverters for I/O wiring are available to protect the wireless unit.



## **EUROPEAN PLANT AND OFFICES**

Z.I. Est – rue Orfila CS 20417 – 62027 Arras Cedex FRANCE

Tél: +33 (0)3 21 60 80 80 – Fax: +33 (0)3 21 60 80 00

Website: <http://www.oldhamgas.com>

### **AMERICAS**

Tel: +1-713-559-9280

Fax: +1-281-292-2860

[americas@oldhamgas.com](mailto:americas@oldhamgas.com)

### **ASIA PACIFIC**

Tel: +86-21-3127-6373

Fax: +86-21-3127-6365

[sales@oldhamgas.com](mailto:sales@oldhamgas.com)

### **EUROPE**

Tel: +33-321-608-080

Fax: +33-321-608-000

[info@oldhamgas.com](mailto:info@oldhamgas.com)